













# DRESS SHIRT



Item No.	Machine Model	Sew Type	Application
1	KW-1390		Counterstich sleeve
2	KW-1757F KW-1816		Attach sleeve
3	KW-1380		Sew front fly to left front
4	KW-2908		Sew button on front
5	KW-1390		Sew pocket
6	KW-2918		Sew buttonhole on front
7	KW-2908		Sew button to top of front & cuff
8	KW-2832		Sew side & under sleeve
9	KW-2918		Sew buttonhole to top of front & cuff
10	KW-1390		Sew yoke to back
11	KW-1370		Runstitch cuff